


















# ASSEMBLY INSTRUCTIONS

- A**  5PCS
- B**  1PC
- C**  1PC
- H** 5/16"x19mm  3PCS
- D** 1/4"x41mm  6PCS
- I** Ø19x1.5mm  3PCS
- E** 1/4"x57mm  2PCS
- J** Ø13x1mm  6PCS
- F** 1/4"x45mm  2PCS
- K** 5mm  1PC
- G** Ø15x1mm  4PCS




Do not tighten bolts fully until you have completed assembly.  
Should you require any assistance in assembling your goods please contact customer services on 0151 548 7111 between 9am/4:30pm.



## WARNING

- DO NOT USE THIS CHAIR AS A STEPLADDER
- USE THIS PRODUCT ONLY FOR SEATING ONE PERSON AT A TIME
- DO NOT USE THIS CHAIR UNLESS ALL BOLTS, SCREWS AND KNOBS ARE FIRMLY SECURED
- AT LEAST EVERY 4 MONTHS CHECK ALL BOLTS, SCREWS AND KNOBS TO BE SURE THEY REMAIN TIGHT
- IF PARTS ARE MISSING, BROKEN, DAMAGED OR WORN, STOP USING THE PRODUCT UNTIL REPAIRS ARE MADE USING AUTHORIZED PARTS
- FAILURE TO FOLLOW THESE INSTRUCTIONS/WARNINGS COULD RESULT IN SERIOUS INJURY

**dams**  **RON300T1**