


# MULTI - FUNCTION RUGGED CASE

## INSTALLATION GUIDE


### STEP 1

Pull away from the edge,  
remove back cover.




### STEP 2

Pull away and unclip from the  
edge buckle, remove the face  
cover and back case.




### STEP 3

Put the tablet in the case,  
ensuring the correct orientation.



### STEP 4

Install the face cover, fasten  
the buckles tightly, and  
install the back cover.



eschner  
function with emotion