


ASSEMBLY NOTE:


HAND TIGHTEN ALL NUTS AND BOLTS DURING ASSEMBLY.

AFTER ASSEMBLY SECURELY TIGHTEN ALL NUTS AND BOLTS.

ROUND PICNIC TABLE / BENCH

MODEL 277150 BL/GN/BK
ASSEMBLY INSTRUCTION



CONTENTS					
REF.	QTY.	DESCRIPTION	REF.	QTY.	
1	4	RIGHT LEG	H1	28	M8x1.25 x 1.3125 lg 
2	1	TOP			
3	4	LEFT LEG	H2	56	Plain Washer 
4	1	LEG SUPPORT			
5	4	BENCH	H3	28	M8x1.25 lock nut 

