









www.globalindustrial.com
1-800-645-1232
ADJUSTABLE HEIGHT

WORKBENCH ASSEMBLY INSTRUCTION

CONTENTS	
REF.	QTY.
1	2
2	4
3	2
4	1
5	2
6	1
DESCRIPTION	
LEG	
LEG EXTENDER	
STRINGER	
FOOT REST	
DRAWER SUPPORT	
TOP	
H1	8
H2	8
H3	8
H4	8
H5	12
H6	8
H7	2
H8	2
H9	4
H10	4
H11	10
	1








www.globalindustrial.com




1-800-645-2986

OPTIONAL CASTER MOUNT ASSEMBLY

ASSEMBLY INSTRUCTION



CONTENTS		
REF.	QTY.	DESCRIPTION
1	4	LEG EXTENDER
H1	16	
H2	32	
H3	4	
H4	16	



NOW THAT YOU HAVE ASSEMBLED THE NEW MOBILE LEG, FOLLOW THE BENCH ASSEMBLY INSTRUCTION PACKED WITH THE BENCH.