

# Diversey

# Suma® Calc D5 Descaler



A concentrated, acidic cleaner for the removal of lime scale from kitchen equipment and utensils as well as for descaling dishwashing machines.

#### **Effective**

- Removes lime scale—protecting equipment and improving assurance of hygiene
- Brightens dull metal surfaces by removing oxide fi lm

#### Versatile

 Safe on stainless steel, glass, copper or plastic when used as directed

#### **Economical**

• Excellent cost in use by concentrated formulation

## Suma® Calc D5

#### Descaler



#### **Use Directions**

#### Descaling-Brush or Soak

- Prepare ½ to 1 ounce of delimer per gallon of water and flood or brush onto surface to be cleaned or descaled. If used on aluminum surfaces, do not exceed ¼ ounce delimer per gallon.
- Soak for 10 minutes and rinse.

#### **Descaling Commercial Dishwasher**

- Add delimer to wash, power rinse and scrapper tanks at 2 to 8 ounces per gallon of water depending on the amount of scale present.
- Circulate solution for 10 to 30 minutes at normal machine operating temperatures. Drain and rinse.

#### For Food Plant Use

- All food contact surfaces must be thoroughly rinsed with potable water after treatment with this product. Avoid contamination of food during use or storage.
- Precaution: For safe useage do not mix this product with anything but water. Use as directed by your Diversey representative.

#### **Product Specifications**

Description	
Certifications	Kosher, CFIA
Color/Form	Clear red, aqueous solution
Flash Point	>200° F (> 93.3° C)
рН	0.5
Scent	No fragrance added
Shelf Life	2 years
Solubility	Complete
Specific Gravity	1.068

#### Available Items

Product Code	Description/Package Size	Dilution
95330615 == 5330615   <b>*</b>	4 x 1 gallon / 3.78 L Containers	1:15–1:256

### Safety Reminder

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use, and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDSs are available on-line at www.sealedair.com or by calling 888 352 2249. Improper use or dilution may result in damage to surfaces and may result in health and physical hazards that match those of the concentrate. Please refer to the Diversey HazMat Library, only available through Internet Explorer, http://naextranet.diversey.com/dot/, for up to date shipping information.