

Veneto Executive

User Guide




Seat height adjustment

Whilst seated locate the adjustment lever underneath the seat (RHS). Lift the lever and the seat will lower. To raise the seat, lift the same lever whilst taking your weight off the seat.



Lumbar support adjustment

Whilst seated simply slide the lumbar support up or down to the desired position.



Seat depth adjustment

Whilst seated locate the lever underneath the seat (LHS). Lift the lever to release the seat and slide it to your desired position. The sprung mechanism will automatically return the seat back to min. depth when the lever is raised with no weight on the seat.



Headrest adjustment

Hold the headrest with both hands and gently pull up or push down to adjust height.



Synchro mechanism tension adjustment

Whilst seated locate the adjustment handle underneath the seat (RHS). Twist clockwise (forwards) to increase the resistance of the tilt mechanism or anticlockwise (backwards) to reduce resistance. Adjust the chair to be in equilibrium to your own body weight.



Armrest position adjustment

To raise or lower the armrest depress the button underneath the armrest pad. To adjust the pad position slide it forward/backward or twist left/right.



Backrest angle lock adjustment

Whilst seated locate the adjustment handle underneath the seat (LHS). To lock the backrest position, twist the handle clockwise (forwards). To unlock, twist the handle clockwise (backwards).