



MCM25E

Ergonomic Cable Managed Leg Frame




RIGHT HAND ERGONOMIC DESK SHOWN










ALWAYS HANDLE ITEMS WITH CARE





IF UNSURE CALL FOR ASSISTANCE






KEEP FITTINGS AWAY FROM CHILDREN















Please check that you have all the hardware!













Step 4 Insert the minifix cams into the side panel. Ensure they are inserted into the LH side of the panel and that the fitting is pushed all the way down and the arrow guideline is aligned with the hole in the edge of the panel.

For LH Desk assembly see Dia B








5

Step 5

Attach the 800mm leg to the desktop using the M6x50mm connect bolts.











Step 6

Attach the modesty panel to the leg using the 70mm confirmat screws.













Place the 600mm leg frame onto the desktop and attach to the modesty panel using the 70mm confirmat screws.









<u>Step 10</u>

Fix the 600mm leg frame to the desktop using the M6x50mm connect bolt, do not insert the rear fixing at this point, this is inserted during the final step of installation.









Fix the corner post leg to the desktop using the 20mm wood screw.








(12)



2 Man Lift Required


Please note this requires a 2 man lift.
The desk is extremely heavy when fully assembled, always ensure that the table is lifted by the frame and not the dektop.




Feed any cables up through the cable channel from the inside of the leg. If needed use the cable ties to fasten them to the cable channel.




Insert the cable cover into the opening between the uprights.






17

Step 17
Attach the cable covers to the 800mm leg frame using the M6x10mm thumbscrews.







Feed any cables up through the cable channel from the inside of the leg. If needed use the cable ties to fasten them to the cable channel.

Step 19

19

Insert the cable cover into the opening between the uprights.





Step 20

bolt, this bolt should pass through the leg and fix directly into the threaded insert in the desktop.

Step 21

21

Attach the cable cover using the M6x50mm connect Attach the cable cover using the M6x10mm thumbscrew.

