

Diversey

Citrus Express Gel^{™/MC}

All Purpose Gelled Solvent Spotter



A versatile, daily, citrus-based solvent spotter that removes gum, oils, grease and ink.

Easy-to-Use

- Unique solvent and detergent formula easily removes solvent- based spots quickly and easily, without damage to carpet backing
- Removes gum, oil, grease, ink and marker

Versatile

- Hard surface removal for graffiti and adhesive residue
- Pleasant citrus scent

Designed For

- Healthcare
- Education
- Retail
- BSC
- Government

____|*|

Use Overview



Citrus Express^{TM/MC} Gel All Purpose Gelled Solvent Spotter is a unique solvent and detergent formula which easily removes solvent-based spots quickly and easily, without damage to carpet or backing.

- Pretest. If being used for the first time, test for colorfastness in an inconspicuous area before use.
- Apply to stain.
- Agitate with bone scraper. Let stand for 10 minutes.
- Remove excess soil and product with scraper and blot with clean cloth and brush until no more spotting occurs on cloth.
- Repeat if necessary.
- Rinse thoroughly with water and blot dry or extract.



Product Specifications

Description	
Color/Form	Milky white liquid
Flash Point	>147.9° F (>64.4° C)
рН	9.3 (Concentrate)
Scent	Citrus
Shelf Life	2 years
Solubility	Complete
Specific Gravity	0.98

Hazard Rating

HMIS		NFPA
2	Health	2
2	Flammability	2
0	Reactivity	0

4=Very High; 3=High; 2=Moderate; 1=Slight; 0=Insignificant.

Available Items

Product Code	Description/Package Size	Dilution
95002523 = 5002523 •	6 x 1 U.S. Qt / 946 mL Squeeze Bottles	Ready-to-Use

Safety Reminder

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use, and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDSs are available on-line at www.sealedair.com or by calling 888 352 2249. Improper use or dilution may result in damage to surfaces and may result in health and physical hazards that match those of the concentrate. Please refer to the Diversey HazMat Library, only available through Internet Explorer, http://naextranet.diversey.com/dot/, for up to date shipping information.