




FZ1600OL Fuze Outer Leg



Used to build





Fuze Back to Back Desk





Fuze Boardroom Table



**TOOLS REQUIRED
FOR ASSEMBLY**




**DONT STRUGGLE
2 MAN LIFT**





**ALWAYS HANDLE
ITEMS WITH CARE**



**IF UNSURE CALL
FOR ASSISTANCE**




**KEEP FITTINGS AWAY
FROM CHILDREN**







Please check that you have all the components



2 x DESK TOP

800mm Deep Tops


1200mm = ED128T
1400mm = ED148T
1600mm = ED168T




1 x TABLE TOP

1600mm Deep Tops


1200mm = EDBT1216T
1600mm = EDBT1616T




or










2 x OUTER LEG FRAMES (FZ1600OL)




2 x OUTER LEG PANELS (FZW-1)




FITTINGS SUPPLIED WITH EACH LEG

4x  Leg Spacer Block	4x  M8 x 50mm Bolt
4x  Beam Infill Block	4x  8mm Washer
2x  M8 Adjustable Foot	8x  M6 x 60mm Connect Bolt
	8x  M6 x 25mm Connect Bolt



2 x BEAM PACK

1200mm = ED12BM
1400mm = ED14BM
1600mm = ED16BM







Back to Back Desk Assembly

1

Step 1

Insert the beam infill blocks into both ends of the beam.




2

Step 2

Push the beams onto the 1st leg frame lining up the beam holes with the M6 threaded holes on the leg.


Ensure the screen fixing points on the outer leg and cut out slots on the beams are facing inwards.




3

Step 3

Once the holes are aligned fix the beam in place using the M6 x 25mm Connect Bolts.



8x




M6 x 25mm Connect Bolt

4


Step 4

Push the beams onto the remaining leg frame lining up the beam holes with the M6 threaded holes on the leg.



Please Note

If you have purchased a larger configuration of desk than the one shown please refer to the FZ1600IL instruction before proceeding with step 4




5


Step 5

Once the holes are aligned fix the beam in place using the M6 x 25mm Connect Bolts.

8x



M6 x 25mm Connect Bolt




Please Note

If you have purchased a sliding top system please refer to the sliding top bracket assembly instruction from this point onwards.



Step 6

Position the Spacer Blocks over the holes in the leg frames.

8x

Leg Spacer Block

Ensure that the spacer blocks are placed onto the frame with the recessed nut holes facing upwards.


**Please Note**

For ease of assembly Screen Brackets and Horizontal Cable Trays should be fitted before you proceed to Step 7.


Step 7

Place the desktop onto the assembled framework ensuring that the edges of the desktop finish parallel with the end of the leg frames.

The framework may be slightly out of square, if this happens loosen the fixing bolts in the beams and align correctly before re tightening the bolts.





or



Step 8

Attach one side of the desktops to the frame using the M6 x 60mm Connect Bolts.

Ensure that the bolt passes through both the leg frame and Spacer Block.



**8x**

M6 x 60mm Connect Bolt

Step 9


Attach the remaining side of the desktops to the frame using the M6 x 60mm Connect Bolts.

Ensure that the bolt passes through both the leg frame and Spacer Block.


**8x**

M6 x 60mm Connect Bolt


FZ1600IL Fuze Inner Leg



Used to build




Fuze Back to Back Desk



Fuze Boardroom Table





Please check that you have all the components



1 DESK TOP
(Number of tops is dependant on configuration)

800mm Deep Tops


- 1200mm = ED128T
- 1400mm = ED148T
- 1600mm = ED168T




1 TABLE TOP
(Number of tops is dependant on configuration)

1600mm Deep Tops


- 1200mm = EDBT1216T
- 1600mm = EDBT1616T




OR










1 x INNER LEG FRAMES (FZ1600IL)




1 x INNER LEG PANELS (FZW-2)




FITTINGS SUPPLIED WITH EACH LEG

4x  Leg Spacer Block	4x  M8 x 50mm Bolt
4x  Beam Infill Block	4x  M8 Knock In Insert
2x  M8 Adjustable Foot	8x  M6 x 60mm Connect Bolt
	8x  M6 x 25mm Connect Bolt



4 BEAM PACK
(Number of beams is dependant on configuration)




- 1200mm = ED12BM
- 1400mm = ED14BM
- 1600mm = ED16BM



Back to Back Desk Assembly

Please Note


This assembly instruction follows on from step 3 on the outer leg assembly instruction FZ1600OL



4

Step 4

Push the beam onto the Inner leg frame lining up only the outer beam holes with the M6 threaded holes nearest the edge on the leg.




5


Step 5

Once the holes are aligned fix the beam in place using the M6 x 25mm Connect Bolts.

4x



M6 x 25mm Connect Bolt





6

Step 6

Push the next set of beams onto the inner leg frame lining up only the outer beam holes with the M6 threaded holes nearest the edge on the leg.

Ensure the cut out slots on the beams are facing inwards.




7


Step 7

Once the holes are aligned fix the beam in place using the M6 x 25mm Connect Bolts.

4x



M6 x 25mm Connect Bolt




8

Step 8

Push the beams onto the remaining outer leg frame lining up the beam holes with the M6 threaded holes on the leg.

Ensure the screen fixing points on the outer leg are facing inwards.




9


Step 9

Once the holes are aligned fix the beams in place using the M6 x 25mm Connect Bolts.

8x



M6 x 25mm Connect Bolt



Please Note


If you have purchased a sliding top system please refer to the sliding top bracket assembly instruction from this point onwards.

10

Step 10


Position the Spacer Blocks over the holes in the leg frames.

12x




Leg Spacer Block

Please Note
For ease of assembly Screen Brackets and Horizontal Cable Trays should be fitted before you proceed to Step 11.




Ensure that the spacer blocks are placed onto the frame with the recessed nut holes facing upwards.




Step 11

Place the desktop onto the assembled framework ensuring that the edges of the desktop finish parallel with the end of the leg frames.

The framework may be slightly out of square, if this happens loosen the fixing bolts in the beams and align correctly before re tightening the bolts.




or



Step 12

Attach the desktops to the frame using the M6 x 60mm Connect Bolts.

Ensure that the bolt passes through both the leg frame and Spacer Block.

24x

M6 x 60mm Connect Bolt

