

## Technical Data Sheet 10/25/2017

## Floor Patch™

**Description:** All-purpose concrete patching compound that bonds to concrete, brick, masonry, metal, or wood surfaces.

Intended Use: Ideal for patching concrete, brick, masonry, floors, or retaining walls where the concrete has spalled. The material will also bond to wood and metal. Can be used to anchor bolts in concrete.

Product Easy to mix and apply features: Trowelable to 1/4" or more High compressive strength Resistant to water, oils, solvents, and alkalis

None

Limitations:

Typical Physical Properties: Technical data should be considered representative or typical only and should not be used for specification purposes.

Physical Properties:	Cured 7 days @ 75° F Application Coverage per Unit Application Temperature Chemical Immersion Color Compressive Strength Cure Hardness Functional Cure Minimum Recoat Time @ 75F Mix Ratio Mixed Viscosity Pot Life @ 75F Solids by Volume Temperature Resistance	4. sq.ft. @ 1/4"/10 lb.unit * 60° - 90°F 7 days @ 75°F Light Grey 8000 psi 85D 16 hours @ 75°F 6 - 8 hrs. 5.5:1 weight. 4.5:1 volume Putty - Paste 45 min. 100 Dry: 250°F; Wet: 120°F			
	Uncured Aggregate/Liquid Ratio	6:1 by weight; 4:1 by volume			
Surface Preparation:	<ul> <li>For METAL SURFACES, use a wire brush or sandpaper to remover rust and scale from the surface to be protected. Surfaces may be shot blasted or abraded using a wire wheel for best results. All dirt, grease, and old paint should be removed. All clean dry surface is essential for the best results.</li> <li>Begin with a sound, clean, dry and roughened, oil-free application surface, as it is essential to the success and performance of this product.</li> <li>Spot test surface by mixing a small quantity of the resin and hardener without the silica filler. Apply the compound to a small, clean test area. Old paint may wrinkle or lift. If it DOES NOT, wait five (5) days and test the bond strength by scraping surface with a sharp instrument. A pressure-sensitive tape test can also be used as follows: cut an "X" into surface and place tape firmly over the cut. Remove the tape with a hard, fast pull. If the coating fails either test, proceed with instructions for previously coated concrete (see below).</li> <li>For NEW POURED CONCRETE, allow to fully cure (28 days @ 70°F) prior to application. Remove any curing membrane by sanding or etching with a strong detergent.</li> <li>For OLD CONCRETE, thoroughly clean surface with a grease-cutting detergent to remove grease and oils, and remove any loose or unsound concrete by chipping, scarifying, shotblasting, sanding, or grinding. Proceed as for new poured concrete.</li> <li>For PREVIOUSLY COATED CONCRETE, applications should be considered short term because the coating system is only as strong as its weakest component. Remove any peeling or degraded paint by sanding or using a paint stripper. For</li> </ul>				
	only as strong as its weakest component. Remove any peeling or degraded paint by sanding or using a paint stripper. For intact paint, thoroughly clean the surface with a strong detergent, then lightly sand to remove any gloss. Treat any areas worn down to the original concrete as bare concrete.				

Mixing Instructions:	<ul> <li>Adequate ventilation is necessary when mixing this product</li> <li>Attach a propeller-type Jiffy Mixer Model ES to an electric drill.</li> <li>Shake Resin and hardener well before use.</li> <li>Add resin to pail and mix thoroughly until color is uniform.</li> <li>Add hardener into resin pail.</li> <li>Mix for about two (2) minutes, while continuously scraping material away from sides and bottom of container.</li> <li>Slowly and evenly, pour aggregate into liquid mixture and mix until a uniform texture is obtained.</li> </ul>					
Application Instructions:	Spread Floor Patch™ over application area with a trowel. Spread back and forth to create the top layer. To produce a smooth finish, trowel again once product has thickened (approx. 20 minutes into pot life).					
	FOR A TRULY SMOOTH FINISH: Dip trowel in water before each application to lessen build-up on trowel and break surface tension of epoxy. DO NOT pour water onto uncured epoxy.					
Storage:	Store at room temperature, 70 °F.					
Compliances:	Approved in the U.S. for use in meat and poultry processing plants. Accepted by Canadian Department of Agriculture Food Safety Service					
Chemical	Chemical resistance is calculated	with a 7 day, room terr	p. cure (30 days immersion) @	⊉ 75°F)		
Resistance:	Ammonia	Very good	Toluene	Poor		
	Chlorinated Solvent	Very good				
	Hydrochloric 10%	Very good				
	Kerosene	Very good				
	Methanol	Fair				
	Perchloroethylene	Fair				
	Sodium Hydroxide 10%	Very good				
	Sulfuric 10%	Very good				
Precautions:	Please refer to the appropriate material safety data sheet (MSDS) prior to using this product. For technical assistance, please call 1-855-489-7262 FOR INDUSTRIAL USE ONLY					
Warranty:	Devcon will replace any material found to be defective. Because the storage, handling and application of this material is beyond our control, we can accept no liability for the results obtained.					
Disclaimer:	All information on this data sheet is based on laboratory testing and is not intended for design purposes. ITW Polymers Adhesives North America makes no representations or warranties of any kind concerning this data.					
Order Information:	13100 10 lb. 13120 40 lb.					