

Fellowes

Ergonomic Solutions



Easy Glide™
Writing/Document Slope

Easy Glide™

Writing/Document Slope


Features:

- Work inline and maintain good posture when using documents and writing to avoid neck and back discomfort
- Achieve the perfect ergonomic position with 6 height and angle settings.
- Contoured ledge supports catalogues, books, and paperwork up without causing discomfort
- Platform effortlessly glides forward, maximising desk space and creating an ergonomic writing area.
- Built in, hidden accessory tray with charging cable access
- Independently tested to meet ergonomic requirements outlined in European Health and Safety Legislation: EN ISO 9241-5.



Specification:

Code	8210001
Colour	Black
Product Dimensions (H x W x D)	11.60 x 57.50 x 38.00 cm
Product Weight	5.66 kg
Retail Packaging Dimensions (H x W x D)	17.50 x 61.50 x 44.00 cm
Retail Packaging Weight	5.96 kg
Outer Carton Dimensions (H x W x D)	37.00 x 46.00 x 63.00 cm
Outer Carton Weight	12.86 kg
Number of Height Adjustments	6
Height Range	11.8/14.8/17.6/20.4/23/25.3 cm
Angle Range	7/13.5/19/25.4/31.4/37.5°
Sheet Capacity	250-500
Weight Capacity	5 kg
Paper Size	A4 & A3
Line Guide	-
Features	Magnetic Hidden storage tray with cable charging access
Retail Barcode (UPC)	043859706396
Outer Carton Barcode (SCS)	50043859706391
Quantity per Outer Carton	2
Warranty	1 year limited



Ergonomic design

Work inline and maintain good posture when using documents and writing to avoid neck and back discomfort



Gliding platform

Platform effortlessly glides forward, maximising desk space and creating an ergonomic writing area. Hidden accessory tray with device charging access and cable management.




Height Adjustable

6 height settings for correct ergonomic positioning

Recyclability:


Product

- Recyclable
- Non Recyclable



Packaging

- Recyclable
- Non Recyclable



Ergonomic Working:




ZONE 3

RELIEVE NECK STRAIN

Achieve comfortable reading
Ensure your eyes are in line with
paperwork by positioning it vertically.

How to use a writing/document slope

- 1. Position:** Place the slope between your monitor and your keyboard, keeping your documents and keyboard directly in front of your body.
- 2. Check screen position:** Ensure that your main monitor is positioned at approximately arm's reach with the top of the screen roughly level with your eyes.
- 3. Viewing documents:** Adjust the angle of your writing/document slope so that the platform's top is level with the bottom of your screen. Magnets and line guides can help keep paper in place and help you navigate to text faster.
- 4. Writing:** Lower the writing slope to its lowest position and pull the platform so that it is positioned over your keyboard, towards the edge of the desk. It should create a flat stable platform for writing without you having to lean forwards.
- 5. Lighting:** Make sure you have suitable lighting to view your documents.



Certifications:

EN ISO 9241-5 1999 Ergonomic requirements for office work with visual display terminals (VDT's): part 5: 1999, workstation layout and postural requirements.



Aftercare:

Cleaning: Wipe over with a damp microfibre cloth. Do not use any cleaning solutions.

Handling & Storage: Read and follow all instructions and warnings before use. This product is intended for indoor use only.

Dimensional Drawings:

