


www.teknikoffice.co.uk

Teknik



It's addicting.

Canyon Lane Lift up Coffee / Work Table

Model 5431214



NOTE: THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION.

PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Lot # **575146**


Purchased: _____

12/13/21

Table of Contents

Assembly Tools Required


Part Identification	3
Hardware Identification	4
Hardware Usage Guide	5
Assembly Steps	5-17
Français	18-19
Español	20-21
Safety	22
Warranty	23



No. 2 Phillips Screwdriver
Tip Shown Actual Size


Part Identification

Now you know
our ABCs.



















- ⚠ While not all parts are labeled, some of the parts will have a label or an inked letter on the edge to help distinguish similar parts from each other. Use this part identification to help identify similar parts.

A	TOP (1)
B	BOTTOM (1)
C	PANEL (2)
D	LEFT END (1)
E	RIGHT END (1)
F	BRACE (1)
G	LEG (4)



Hardware Identification


⚠ Screws are shown actual size. You may receive extra hardware with your unit.

- | | | | |
|--|---|--|--|
| 1 HIDDEN CAM - 4
 | 2 CAM SCREW - 4
 | 3 WOOD DOWEL - 10
 | 4 L-WRENCH - 1
 |
|--|---|--|--|
-
- | | | |
|---|--|--|
| 5 LIFT TABLE MECHANISM SET - 1
 | 6 STRETCHER - 1
 | 7 WASHER - 2
 |
|---|--|--|
-
- | | | |
|---|---|--|
| 8 BUSHING - 2
 | 9 APPLIQUE CARD - 1
 | 10 BUMPER CARD - 1
 |
|---|---|--|
-
- | | |
|--|--|
| 11 1-9/16" PAN HEAD SCREW - 10
 | 12 13/16" HEX HEAD SCREW - 8
 |
|--|--|
-
- | | |
|---|--|
| 13 11/16" MACHINE SCREW - 2
 | 14 9/16" PAN HEAD SCREW - 22
 |
|---|--|
-
- | | |
|--|--|
| 15 1/2" HEX HEAD SCREW - 4
 | 16 3/8" PAN HEAD SCREW - 2
 |
|--|--|


Hardware Usage Guide

HOW TO USE A HIDDEN CAM & CAM SCREW OR CAM DOWEL


1. NOTE: Various CAM SCREWS or a CAM DOWEL may be used.




Turn the CAM SCREW or gently tap the CAM DOWEL until the shoulder is against the surface of the part.



- 2.




Push a HIDDEN CAM into the part. The arrow in the HIDDEN CAM must point toward the hole in the edge of the board.



- 3.

Insert the CAM SCREW or CAM DOWEL into the HIDDEN CAM. Tighten the HIDDEN CAM.





Step 1

- ✚ Assemble your unit on a carpeted floor or on the empty carton to avoid scratching your unit or the floor.
- ✚ Turn four CAM SCREWS (2) into the PANELS (C).
- ✚ Push four HIDDEN CAMS (1) into the ENDS (D and E).




Don't worry. It isn't Rome. This can be built in a day.




Step 2

- ✚ Insert four WOOD DOWELS (3) into the PANELS (C).
- ✚ Fasten the PANELS (C) to the ENDS (D and E).
Tighten four HIDDEN CAMS.
- ✚ NOTE: Be sure the WOOD DOWELS in the PANELS insert into the ENDS.




Step 3

- ✚ Insert six WOOD DOWELS (3) into the PANELS (C) and ENDS (D and E).
- ✚ Fasten the BOTTOM (B) to the PANELS (C) and ENDS (D and E). Use ten 1-9/16" PAN HEAD SCREWS (11).
- ✚ NOTE: You should start each SCREW a few turns before completely tightening any of them.




Step 4

- ⚠ **NOTE:** Do not completely tighten the SCREWS in this step.
- ⚠ Fasten the BRACE (F) to the LEGS (G). Tighten four 1/2" HEX HEAD SCREWS (15) using the L-WRENCH (4).



Step 5

- ✚ Fasten the LEGS (G) to the BOTTOM (B). Tighten eight 13/16" HEX HEAD SCREWS (12) using the L-WRENCH (4).
- ✚ NOTE: You should start each SCREW a few turns before completely tightening any of them.
- ✚ Completely tighten the SCREWS in the BRACE (F).




Step 6

- ✚ Insert the STRETCHER (6) into the posts on the LIFT TABLE MECHANISM SET (5).
- ✚ NOTE: The STRETCHER will be fastened in a later step.




Now might be a good time to refresh your drink.




Step 7

- ✚ **1st** Fasten the front edge of one LIFT TABLE MECHANISM (5) to the TOP (A) as shown. Use four 9/16" PAN HEAD SCREWS (14).
- ✚ **2nd** Hold the LIFT TABLE MECHANISM (5) down to access the back hole.
- ✚ **3rd** Fasten the back edge of the LIFT TABLE MECHANISM (5) to the TOP (A). Use one 9/16" PAN HEAD SCREW (14).
- ✚ Repeat this step for the other LIFT TABLE MECHANISM as shown.



Step 8


- ✚ **IMPORTANT:** You will need someone's help in this step.
- ✚ Carefully stand your unit upright.
- ✚ Fasten the LIFT TOP MECHANISMS (5) to the ENDS (D and E). Use twelve 9/16" PAN HEAD SCREWS (14) through the LIFT TABLE MECHANISMS (5) and into the holes in the ENDS as shown in the enlarged diagram.
- ✚ **NOTE:** Be careful when lining up the holes in the MECHANISMS with the holes in the ENDS as to not damage any parts. You should start each SCREW a few turns before completely tightening any of them.



Step 9


- Fasten the BUSHINGS (8) to the ENDS (D and E). Use two 11/16" MACHINE SCREWS (13) through the BUSHINGS, through two WASHERS (7), through the LIFT TABLE MECHANISMS (5), and into the ENDS.

NOTE: Do not overtighten the SCREWS.




Step 10

- ✚ Fasten the LIFT TOP MECHANISMS (5) to the STRETCHER (6). Use two 3/8" PAN HEAD SCREWS (16).



Step 11

- Peel BUMPERS from the BUMPER CARD (10) and stick them onto the edges of the PANELS (C) as shown.



Step 12

- ✚ **IMPORTANT:** Do not place valuables in the storage space.
- ✚ Peel APPLIQUES from the APPLIQUE CARD (9) and stick them onto each visible HIDDEN CAM.
- ✚ **NOTE:** Please read the back pages of the instruction booklet for important safety information.
- ✚ This completes assembly. Clean with a damp cloth. Wipe dry.

